# FRIDGE FREEZER

User Manual

Model Number: CF60200NFW




SERVIS
EFFICIENCY BY DESIGN

Visit servis.co.uk

# Contents›


01 Welcome

02 Safety Instructions

07 Advanced Features

09 Your Fridge Freezer

12 Electrical Information

13 Technical Specification

14 Installation

17 Usage

18 Food Storage Tips

22 Cleaning and Care

25 Troubleshooting

27 Guarantee

29 Index





Visit servis.co.uk

T: 0333 577 7232

## WELCOME ›

Thank you for choosing this Servis Fridge Freezer, which has been designed and manufactured to give you many years of trouble-free service.
You may already be familiar with using a similar product but please take time to read these instructions, which have been written to ensure you get the very best from your purchase.

## WARRANTY ›

Servis provides you with a guarantee which will protect you should your Fridge Freezer develop an electrical or mechanical fault during the guarantee period. To ensure that you get a prompt and efficient service, please register your Fridge Freezer immediately.
You will find a warranty card included within the packaging. To register, complete the form, or:

» Visit us at www.servis.co.uk

» Call us on 0333 577 7232

## ITEMS INCLUDED ›

Fridge Freezer Complete with Shelves and Drawers






Figure 1





**To ensure your safety and the safety of others, please read the following safety precautions before you use your Fridge Freezer.**

» Your Fridge Freezer conforms to current safety requirements. Inappropriate use can, however, lead to personal injury and damage to property. To avoid the risk of accidents and damage to your Fridge Freezer, read this user guide carefully before using it for the first time. It contains important information on the installation, safety, use and maintenance of your Fridge Freezer. Retain this user guide for future use and pass it on to any new owners. Read this user guide before using or installing your Fridge Freezer.

» Do not expose your Fridge Freezer to moisture or rain.

» Always remove the mains plug from the wall socket when not in use or before any service operation.

» Your Fridge Freezer is for domestic use only and is only intended for the storage of edible foodstuffs.

» This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

» Before setting up your Fridge Freezer, check for any external visible damage. Do not install or use your Fridge Freezer if it is damaged.

» Before connecting your Fridge Freezer, ensure that the information on the data plate (voltage and connected load) matches that of the mains electricity supply. If in doubt, consult a qualified electrician.

# SAFETY INSTRUCTIONS ›

- Containers with flammable gases or liquids can leak at low temperatures. Do not store any containers with flammable materials, such as spray cans or fire extinguisher refill cartridges in the vicinity of the Fridge Freezer.
- Do not connect your Fridge Freezer to the mains electricity supply using an extension lead.
- A damaged power cord/plug can cause fire or give you an electric shock. When damaged it must be replaced, this should only be done by qualified personnel.
- Never remove the plug from the socket by pulling the cord. Always hold the plug.
- Never touch the power cord/plug with wet hands as this could cause a short circuit or electric shock.
- Never let the power cord be crushed by the Fridge Freezer itself or other heavy objects.
- Never bend the power cord excessively.
- Never let the power cord touch or pass over heating appliances.
- Do not remove items from the freezer if your hands are damp/wet. This could cause skin abrasions or frost/freezer burns.
- Do not place fizzy drinks, bottles and cans in the freezer compartment as they can burst as the contents freeze.
- Faulty components must only be replaced by a suitably qualified Service Agent using genuine spare parts.
- Unauthorised repairs could result in unforeseen dangers for the user. Repairs should only be undertaken by an approved service agent.



- Do not use other electrical appliances inside the Fridge Freezer.
- Do not refreeze food once it has thawed out.
- Do not make any alterations to your Fridge Freezer, unless authorised to do so by Servis.
- The packaging of the machine could be hazardous to children. Please refer to the disposal instructions on the rear cover.
- Please ensure that you have removed all of the packaging materials and protective tape from your Fridge Freezer before using.
- Please take care when moving your Fridge Freezer. It is heavy and we recommend that a minimum of two people move it. Your Fridge Freezer has a wheel in each back corner. You will find it easiest to move your Fridge Freezer when it is tilted backwards and pushed into position.
- The small quantity of refrigerant used in the Fridge Freezer is eco-friendly R600a (an isobutene) and is flammable/explosive if ignited in enclosed conditions. If the cooler elements have been damaged and you suspect a leak, move the Fridge Freezer away from any heat sources or open flame and ventilate the room the Fridge Freezer is in for a few minutes.
- Because of the very low temperatures in the Freezer compartment, some foods, such as ice lollies could cause frost burns if consumed immediately after being removed from the Fridge Freezer.
- Keep the ventilation openings of the Fridge Freezer clear from obstruction.
- Do not store medicine or academic research samples that require strict temperature control in the Fridge Freezer.

# SAFETY INSTRUCTIONS ›

» When cleaning, do not use sharp implements as they may damage the Fridge Freezer.

» Store pre-packed frozen foods in accordance with their instructions and use by date.

**Ecological Hints and Tips:**

We have provided a few important hints and tips, so that you can save on the cost of energy and help protect the environment.

» Do not install the Fridge Freezer close to sources of heat such as a radiator or a cooker.

» Install the Fridge Freezer in a well ventilated room and keep the openings clear from obstruction.

» Do not install the Fridge Freezer on a wet floor or in a location with high humidity/moisture content.

» Food which is to be frozen (when cool) should be placed in the fridge compartment before being transferred to the freezer.

» Pack all foods into airtight packages before placing them into the freezer compartment.

» Do not place food against the turbo fan, otherwise air circulation within the refrigerator compartment will be impaired.

» Ensure there are no obstructions preventing the doors from closing properly.

» Try to avoid keeping the doors open for long periods or opening the doors too frequently as warm air will enter the cabinet and cause the compressor to switch on unnecessarily often.

» Clean the condenser on the back of the Fridge Freezer at least once a year to make sure it is free from dust and dirt.

**Environmental Information:**

» Once installation is complete, please dispose of the packaging with due regard to safety and the environment. Disposal instructions can be found on the rear cover.

» Your Fridge Freezer does not contain gases which damage the ozone layer, in either its refrigerant circuit or insulation materials.


Visit servis.co.uk

# ADVANCED FEATURES ›

**No Frost Technology:**

Your Fridge Freezer differs from many other standard Fridge Freezers. Other Fridge Freezers may experience ice build up in the freezer compartment due to door openings and humidity in the food. In such Fridge Freezers regular defrosting is required; the fridge has to be periodically turned off, the frozen food moved to a suitable container and the ice which has formed in the freezer compartment removed.

Your 'No Frost' Fridge Freezer prevents such problems by evenly blowing dry cold air into the fridge and freezer compartments through a blower fan (Figure 2). The cold air cools your food evenly and uniformly, preventing humidity and ice build up.

**Odour Filter:**

Your Fridge Freezer includes an odour filter in the fridge compartment. This filter helps prevent bad odours from building up.

**Roller Storage Box:**

Your Fridge Freezer contains a roller storage box at the bottom of the fridge compartment. This box can be used in one of two ways:

1. **As a 0° compartment** - To use the roller storage box as a 0° compartment, leave the roller cover open. You can then use the compartment to store food which should be kept at 0° but not frozen (e.g. fish, rice, etc.) helping to keep them fresh for longer. When the chiller tray becomes dirty, remove it and wash it.

2. **As an extra vegetable compartment** - To use the roller storage box as an extra vegetable compartment, keep the roller cover closed.

## NO FROST TECHNOLOGY ›



Figure 2

## FRONT VIEW ›




Figure 3

The following information will help you to identify the different parts of your Fridge Freezer and provide suggestions on the best way to use them.

**Refrigerator Compartment**

1. Fridge and Freezer Thermostats - see page 16.
2. Light LED - see page 24.
3. Adjustable glass shelves
4. Drain hole - water formed as a result of automatic defrosting flows through this hole into the vaporisation container at the rear of your Fridge Freezer and evaporates.
5. Fresh dial - see page 19.
6. Vegetable drawers (Odour filter behind drawers)
7. Roller storage box - see page 7.
8. Door shelves
9. Bottle shelf

**Freezer Compartments**

10. Freezer drawers

## REAR VIEW ›




Figure 4





1. Condenser.
2. Vaporisation Container.

## ELECTRICAL INFORMATION ›

» Your Fridge Freezer requires a 220-240V, 50Hz mains supply. Do not use any other supply.

» If your plug requires changing because it is not suitable for your socket, or it is damaged, you should consult a qualified electrician.

**Fuse:**

» Replacement fuses should be ASTA-approved to BS1362 and have the correct 13 Amp rating.

» Replacement fuses can be purchased from an electrical supplier.

# TECHNICAL SPECIFICATION ›

## TECHNICAL SPECIFICATION ›

| | |
|---|---|
| Model Number | CF60200NFW |
| Power Source | 220-240 V AC, 50Hz |
| Energy Consumption | 0.849 KWh/24h |
| Freezer Rating | 4 |
| Climate Class | ST/N (16°C - 38°C) |
| Refrigerant Gas | R600a |
| Gas Capacity | 65 gr |
| Freezer Capacity | 72 Lt |
| Fresh Food Freezing Capacity | 4.5 Kg./24h |
| Input Power | 198 W |
| Energy Efficiency Rating | A+ Class |
| Minimum Room Temperature | 16°C |



# INSTALLATION ›

## INSTALLATION REQUIREMENTS ›

Before unpacking and manoeuvring your Fridge Freezer, please take the time to read and become familiar with the following points:

- To avoid risk of injury, please take care when moving your Fridge Freezer. It is heavy and we recommend that a minimum of two people move it. Your Fridge Freezer has a wheel in each back corner. You will find it easiest to move your Fridge Freezer when it is tilted backwards and pushed into position.
- Make sure that your Fridge Freezer can fit through all doorways on route to its final location. The dimensions of your Fridge Freezer (including the handles) are 1700 mm high x 610 mm wide x 655 mm deep.

Your Fridge Freezer should be positioned in a location that meets the following requirements:

- In a dry room that can be ventilated and out of direct sunlight.
- Away from any heat source such as a radiator. If this is unavoidable, a suitable heat insulator should be used (this is not supplied).
- On a suitable floor that will not become damaged, or sag under the weight of the Fridge Freezer.
- At least 500 mm away from stoves, ovens and heater cores and 50 mm away from electrical ovens.
- At least 20 mm away from another freezer.
- Insert the distance adjustment plastic blocks into the condenser and turn them 90° to lock them in position. This will prevent the condenser from touching the wall.
- Do not place anything on top of your Fridge Freezer.

## ADJUSTING THE FEET ›

For safe operation, it is important that your Fridge Freezer is stable and balanced. The two adjustable feet at the front are used to level your Fridge Freezer. Make sure that your Fridge Freezer is level before placing any foodstuffs inside it.

1. To increase the height of the Fridge Freezer, turn the feet clockwise (Figure 5).
2. To decrease the height of the Fridge Freezer, turn the feet anti-clockwise (Figure 5).




Figure 5

## TEMPERATURE CONTROL ›

The thermostat (Figure 6) is used to regulate the temperature in the fridge and freezer compartments. There are separate dials for the fridge (**a**) and freezer (**b**) compartments. Each dial can be set to any value, with **max** being the setting with the lowest temperature. For normal everyday use we recommend setting each dial to just above the mid point of the scale.

1. To raise the temperature, turn the thermostat dial anticlockwise.
2. To lower the temperature, turn the thermostat dial clockwise.

» We do not recommend that you operate your Fridge Freezer in environments colder than $10^0$C as efficiency is reduced.

» Your Fridge Freezer is designed to operate in an ambient temperature of $16^0$C to $38^0$C.




Figure 6

## BEFORE USING YOUR FRIDGE FREEZER ›

- When using your Fridge Freezer for the first time, or after transportation , keep it in an upright position for at least 3 hours before plugging into the mains. This allows efficient operation and prevents damage to the compressor.
- We recommend that you wipe all shelving and trays with a cloth soaked in warm water mixed with a teaspoon of sodium bicarbonate before use. After cleaning, rinse with warm water and dry.
- You may notice a slight odour when using your Fridge Freezer for the first time. This is perfectly normal and will fade away once the fridge starts to cool.
- Before using your Fridge Freezer, make sure that it has been connected to an appropriate mains power supply and is switched on at the socket.
- When using your Fridge Freezer for the first time, set the thermostat to a value of 4 for the first 24 hours.
- Your Fridge Freezer has a 5 minute built in delay function, designed to prevent damage to the compressor. When power is applied to your Fridge Freezer, it will begin to operate normally after 5 minutes.





## FOOD STORAGE GUIDANCE ›

To help you use your Fridge Freezer efficiently, please take the time to read the following tips and guidance.

**Storage Areas:**

The circulation of air within your Fridge Freezer causes areas of different temperatures. It is recommended that you make use of these areas when storing your food.

The coldest area of the fridge compartment is at the bottom, above the vegetable drawer. We recommend that you use this area to store food that will perish easily, such as fish, ready meals, baked goods and dairy products.

The warmest area of your fridge is the top shelf of the door. We recommend that you store butter and cheeses in this shelf.

**Storing food:**

It is best to store you food covered or packaged, to prevent it from drying out, and to prevent smells affecting other food in your Fridge. Store fruit and vegetables loose in the vegetable containers. Avoid storing potatoes, onions and garlic in your refrigerator.

Other tips you might find helpful are:

- Wash your food before storage.
- Allow warm or hot food to cool down before storing. This helps to reduce power consumption.

# FOOD STORAGE TIPS ›

- Keep as much space as possible between your items of food. This allows the cold air to circulate freely around them.
- Take care when storing tropical fruit such as pineapples as they can quickly deteriorate in lower temperatures.
- Divide and separate food into smaller pieces before storage.
- Cover or wrap food to prevent odours. We recommend that you store meat loosely covered as this allows air to circulate around the meat causing the surface to dry slightly, helping to prevent the growth of bacteria.
- Do not store food close to the lamp, or block the cover or the cooling compartment.
- If the vegetable drawers are completely full, slide the Fresh Dial (see page 9) to open the vents. This allows air to circulate around the vegetables helping to keep them fresh for longer.

The table below is a quick guide, showing you the most efficient way to store the major food groups in your refrigerator compartment.

| Food | Storage Duration | Location |
|---|---|---|
| Fruits and Vegetables | 1 week | Loose in Vegetable Drawer * |
| Fish and Meat | 2-3 Days | Wrapped on Glass Shelf * |
| Fresh Cheese | 3-4 Days | Top Door Shelf |
| Butter and Margarine | 1 Week | Top Door Shelf |
| Bottles, Yogurt and Milk | Refer to Packaging | Door Shelf |
| Eggs | 1 month | Door Shelf |

* Alternatively, keep in Roller Storage Box (see page 7).



**The Freezer Compartment:**

You should use the freezer compartment of your Fridge Freezer for storing food for long periods and making ice. Aim to freeze fresh food as quickly as possible so that it keeps its taste and appearance.

It is important that you do not exceed the maximum freezing capacity of your Fridge Freezer, this will help to ensure that your food freezes as quickly as possible. The maximum freezing capacity for freezing within a 24 hour period is 4.5 kg.

The storage durations of frozen food can be changed by a variety of factors, such as; the frequency of the doors opening and closing, thermostat settings, food types and the period of time that elapsed from when the food was acquired to the time it entered the freezer. It is important that you follow the packaging on frozen foods and do not exceed the storage duration. The table below contains some recommendations on freezing.

| Food | Preparation | Storage Duration (Months) | Thawing Period at Room Temperature (Hours) |
|---|---|---|---|
| Beef Steak | Cut into single portions | 6-10 | 1-2 |
| Lamb | Cut into single portions | 6-8 | 1-2 |
| Minced Meat | Packed in convenient portions | 1-3 | 2-3 |
| Sausage | Must be packed | 1-2 | Until Thawed |
| Chicken and Turkey | Packed in convenient portions | 1-2 | 10-12 |

# FOOD STORAGE TIPS ›

| Food | Preparation | Storage Duration (Months) | Thawing Period at Room Temperature (Hours) |
|---|---|---|---|
| Freshwater Fish (such as trout) | Cleaned well inside and scaled. Washed and dried. Cut off head and tail where necessary | 2 | Until Well Thawed |
| Lean Fish (such as Sea Bass) | | 4-8 | Until Well Thawed |
| Fatty fish (such as Mackerel) | | 2-4 | Until Well Thawed |
| Peas | Shelled and washed | 12 | May Be Used From Frozen |

WARNING: Do not re-freeze frozen food once it has thawed. It may be a danger to your health.

**Ice Cube Trays:**

You can make ice cubes using the ice cube trays supplied with your Fridge Freezer;

» Fill each ice cube tray three quarters full with water and place it on the bottom of the freezer compartment.



# CLEANING AND CARE ›

**Power Disruption:**

In the event of a power cut, please do not open the door of the freezer compartment. Your Fridge Freezer will preserve your frozen food in an ambient environmental temperature of 25$^0$C for approximately 13 hours. This time period will be shorter if the ambient temperature is higher. When power is re-applied after a power cut your Fridge Freezer will not operate for 4-5 minutes. This is to allow the gas in the cooling system to balance and is perfectly normal.

## CLEANING AND CARE ›

From time to time it will be necessary to carry out cleaning of your Fridge Freezer.

» Before cleaning your Fridge Freezer, turn your mains power supply off and remove the plug from the socket.

» Do not wash your Fridge Freezer by pouring water on it.

» Use a warm, soapy cloth or sponge to the wipe the interior and exterior of your Fridge Freezer.

» Carefully remove all shelves and drawers by sliding outwards or upwards and clean with soapy water. Do not wash in a washing machine or dish washer.

» Clean the drain hole at the back of the fridge (see page 9) regularly to prevent water collecting in the bottom of the fridge compartment.

» Clean the condenser at the back of your Fridge Freezer at least once a year with a soft brush or vacuum cleaner.

» Do not use solvents, abrasive cleaners, glass cleaners or all purpose cleaning agents to clean your Fridge Freezer. They may damage the plastic surfaces and other components with the chemicals they contain.

# CLEANING AND CARE ›

**Cleaning The Vaporisation  Container:**

Your Fridge Freezer performs fully automatic defrosting. The water formed as a result of this automatic defrosting flows through the drain hole at the back of the fridge (see page 9) into the vaporisation container at the rear of your Fridge Freezer and evaporates. We recommend cleaning the vaporisation container at regular intervals to prevent odours from building up.

To clean the vaporisation container:

1. Remove the vaporisation container by unscrewing the 2 screws (Figure 7 **a** and **b**)
2. Clean the vaporisation container with warm soapy water and dry with a cloth.
2. Re-fit the vaporisation container by screwing it back into position.




Figure 7

**Replacing the LED:**

Contact the Servis helpdesk.

**Replacing the Light:**

To replace the light:

1. Check that your Fridge Freezer is turned off and unplugged from the mains.
2. Apply light pressure to both sides of the light cover and carefully pull the cover away.
3. Unscrew the bulb by turning it clockwise, and remove.
4. Screw in a replacement 15 Watt bulb.
5. Re-fit the light cover, by pushing it until it clicks back into position.



Figure 7

# TROUBLESHOOTING ›

## TROUBLESHOOTING INFORMATION ›

If your Fridge Freezer is not operating as expected, you may find a simple solution listed in the table below.
If your Fridge Freezer has developed a fault not covered in this manual, please contact the Servis helpdesk.

| Fault | Possible Cause | Solution |
|---|---|---|
| Your Fridge Freezer does not operate. | It is switched off at the mains. | Check that your Fridge Freezer is plugged in and turned on at the mains. |
| Your Fridge Freezer does not get cold enough. | The thermostat is set too low. | Turn the thermostat to a higher value. (A setting of 5 will provide the lowest temperature). |
| | The doors are opened and closed too frequently. | Try to reduce the number of times the doors are opened and closed. |
| | The door seals are faulty. | Contact Servis. |
| | The refrigerator compartment is overfilled. | Check that there is enough space between items to allow air circulation. Make sure that no items of food are blocking the air vents. |
| Food in the Freezer compartment is colder than necessary. | The thermostat setting may be too high. | Put the thermostat on a lower setting. |
| Your Fridge Freezer is noisy. | Your Fridge Freezer may not be level. | Adjust the feet to level your Fridge Freezer. See page 15. |
| | Please note that certain noises may heard from your Fridge Freezer during use. They are perfectly normal from a frost free Fridge Freezer and are not damaging your Fridge Freezer. Contact the Servis helpdesk if you have any concerns. | |
| There is moisture on the inner parts of your Fridge Freezer. | The doors are opened and closed too frequently. | Try to reduce the number of times the doors are opened and closed. |
| There is loose water in the bottom of the fridge. | The drain hole at the back of the fridge may be blocked. | Use the drain plug to clear the drain hole. |
| The doors do not close properly. | Items of food may prevent them from closing. | Make sure that the doors are free from obstruction. |
| | The shelves and drawers are not correctly in position. | Check that the shelves and drawers are properly placed in position. |
| | The door seal is damaged. | Contact the Servis helpdesk. |
| | Your Fridge Freezer is not level. | Adjust the feet to level your Fridge Freezer. See page 15. |

# GUARANTEE ›

## DISPOSAL OF YOUR OLD FRIDGE FREEZER ›

All packaging and materials used are environmentally friendly and recyclable. Please dispose of any packaging in an environmentally friendly manner. Consult your local council for further details.

» When the Fridge Freezer is to be scrapped, cut off the electrical supply cable and destroy the plug with the remaining cable. Disable the door catch in order to prevent children from becoming trapped inside while playing. A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Please ensure the cut off plug is disposed of safely.

Please refer to the rear cover for disposal instructions.

## GUARANTEE ›

The Servis guarantee covers the cost of parts/labour/call out charges to repair an appliance should any covered component fail in its normal functions necessitating a repair or replacement to resume those functions.

The Servis guarantee **does not** cover:

» Accidental damage
» Use in a commercial environment
» Incorrect or faulty installation
» Deliberate damage or neglect
» Repairs to cosmetic parts
» Damage caused by foreign objects or substances
» Claims in respect to routine inspection or maintenance

The Servis guarantee is not transferable.
**For your Servis guarantee to be valid, you will need to retain your original purchase receipt and be able to provide it when you make a claim.**

The above summary does not include all of the terms and conditions and exclusions which can be found on our website www.servis.co.uk.

## KNOW YOUR RIGHTS ›

**Household contents insurance**
Your household insurance may cover you for accidental damage, fire or theft of your product.

**Data Protection Act (1988)**
Please note that any information provided will be processed by us or our agents in compliance with the provisions of the Data Protection Act 1988, for the purpose or providing cover and handling claims, if any, which may necessitate providing such information to third parties.

# INDEX ›


**A**

Adjusting the feet ..... 15
Advanced features ..... 07

**B**

Before using your fridge freezer ..... 17

**C**

Cleaning and care ..... 22

**D**

Disposal ..... 27

**E**

Ecological hints and tips ..... 05
Electrical information ..... 12
Environmental information ..... 06

**F**

Food storage guidance ..... 18
Freezer compartment ..... 20
Fuse ..... 12

**G**

Guarantee ..... 27

**I**

Installation requirements ..... 14
Items included ..... 01

**N**

No frost technology ..... 07

**P**

Power disruption ..... 22

**R**

Replacing the light LED ..... 24
Roller storage box ..... 07

**S**

Safety instructions ..... 02

**T**

Technical specification ..... 13
Temperature control ..... 16
Troubleshooting information ..... 25

**W**

Warranty ..... 01





Visit servis.co.uk

T: 0333 577 7232
E: info@servis.co.uk

Visit
servis.co.uk

SERVIS
EFFICIENCY BY DESIGN

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

52140818